



ColorFit

CC cream. Allows your skin tone to match the fast pace of city life. Formula with waterproof properties thanks to Avalure™ Flex-6 has an excellent application properties. You can be sure to have a healthy-looking complexion all day long.

Inside the Formulation

AVALURE™ FLEX-6 POLYMER

A water-dispersible multifunctional powder that provides film formation, pigment dispersion, emulsification, co-thickening and soft feel in skin care applications. Imparts excellent water resistance.

CARBOPOL® AQUA SF-1 OS POLYMER

An acrylates copolymer, alkali-swelling rheology modifier targeting skin care, sun care, and color cosmetic applications containing pigments.

ACTIPHYTE™ ASHWAGANDHA

Known as "Indian winter cherry", and traditionally used in Ayurveda, is believed to be able to impart long life and youthful vigor.

HEMA'TÎTE™

Stone extract, rich in iron. Powerful active for collagen synthesis stimulation: Hema'tîte can be used for anti-aging skin care.

ALT pigments

ALT is a part of Miyoshi's Silicone Treatment line. This product has good color development, excellent water repellency, and has a soft and smooth feel on the skin. It is recommended for powders, dual (2-way) foundations, and liquid foundations.



creating value,
growing together

Formulation reference : 001-3-16

Phase	Raw Material	INCI	%w/w	Supplier
A	Demineralized water	Aqua	29.41	
A	Titriplex III improve	EDTA	0.15	
A	Active Urea	Urea	3.00	Azelis
A	Brontide™	Butylene Glycol	5.00	Genomatica
A	Carbopol® Aqua SF-1 OS Polymer	Acrylates Copolymer	3.00	Lubrizol
A	Blanova Active D-Panthenol 75%	Panthenol, Water	1.00	Azelis
A	Paratexin NIB	Phenoxyethanol, propylparaben, methylparaben, ethylparaben, butylparaben	0.60	Azelis
B	Glycerin	Glycerin	4.00	
B	Rhodicare® S	Xantan Gum	0.20	Rhodia
C	NaOH (sol. 18%)	Sodium hydroxide	0.30	
D	Blanova Shea Butter Refined Organic	Butyrospermum Parkii Butter	1.00	Azelis
D	Compritol® 888 CG Pallets	Glyceryl Behenate	2.00	Gattefosse
D	Labrafac CC	Caprylic/Capric Triglyceride	7.00	Gattefosse
D	Schercemol™ LL ester	Lauryl Lactate	5.00	Lubrizol
D	Blanova GA 20	Octyldodecanol	5.00	Azelis
E	Avalure™ Flex-6 polymer	Polyurethane-62 (and) Trideceth-6	1.00	Lubrizol
F	ALT-C339001-10	Iron Oxides (and) Triethoxycaprylylsilane	1.35	Miyoshi
F	ALT-C338001-10	Iron Oxides (and) Triethoxycaprylylsilane	0.35	Miyoshi
F	ALT-C337001-10	Iron Oxides (and) Triethoxycaprylylsilane	0.14	Miyoshi
F	ALT-TAO-77891	Titanium Dioxide (and) Triethoxycaprylylsilane	8.60	Miyoshi
F	MyioSilk Mica	Mica (and) Dimethicone	3.00	Miyoshi
F	Powder La Vie	Mica (and) Hydroxyapatite (and) Zinc oxide	1.50	Miyoshi
F	Cyclopentasiloxane	Cyclopentasiloxane	11.00	
G	HEMA'TÎTE™	Hematite Extract	1.00	Gattefosse
G	Gatuline® Radiance	Propanediol (and) Evodia Rutaecarpa Fruit Extract	3.00	Gattefosse
G	Magnolia Love 019	Parfum	0.40	IFF



creating value,
growing together

Manufacturing Instructions

Premix phases A and B. Add B to A and mix well. Neutralize to pH 7.

Premix F.

Premix phase D and heat to 75°C. Mix and cool down to 40°C.

Add phase E and F to D.

Add all to phase A and mix well for 15 minutes using whipper or dedicated stirrer.

Add components of phase G and mix until homogenous.

Specification

pH	5.5
Stability Testing	3 months stable @ 45°C, 5°C & RT x 5
Viscosity	40 2000 cP (Brookfield RV Spindle 6, 20 RPM)

Formulation developed by Azelis Personal Care

Disclaimer: Sample formulations are provided for your convenience but Azelis Personal Care does not warrant their merchantability, fitness for use, performance, safety, microbiological profile or freedom from patent infringement. They are not commercial formulations and have not been subjected to extensive testing. It is your responsibility to thoroughly test any formulations before use. All warranties, indemnities or liabilities implied or expressed by law are hereby excluded by Azelis Personal Care to the fullest extent permitted by law.



creating value,
growing together